

Engine Electrical System

GENERAL

CHARGING SYSTEM

ALTERNATOR
BATTERY

STARTING SYSTEM

STARTER
STARTER RELAY

CRUISE CONTROL SYSTEM

PREHEATING SYSTEM

GENERAL

SPECIFICATION EEC7BAAD

STARTING SYSTEM

Item			Specifications
Starter	Type		Reduction drive (with planetary gear)
	Rated voltage		12V, 2.0KW
	No. of pinion teeth		9
	No-load charasteristics	Voltage	11.5V
		Amperage	120A, MAX
		Speed	4,000rpm, MIN
	Commutator diameter	Standard	35 mm (1.378 in)
		Limit	
	Undercut depth	Standard	0.7 mm (0.028 in)
		Limit	

CHARGING SYSTEM

Item		Specifications
Alternator	Type	Battery voltage sensing
	Rated voltage	12V, 120A
	Speed	1,000 ~ 12,000 rpm
	Voltage regulator	I.C regulator built-in type
	Regulator setting voltage	14.4 ± 0.3V
	Temperature compensation	-10 ± 3mV/°C
Battery	Type	MF 90 AH
	Cold cranking amperage at-18°C (0°F)	720A
	Reserve capacity	160min
	Specific gravity at 20°C (77°F)	1.280 ± 0.01



NOTE

- **COLD CRANKING AMPERAGE** is the amperage a battery can deliver for 30 seconds and maintain a terminal voltage of 7.2V or greater at a specified temperature.
- **REVERSE CAPACITY RATING** is amount of time a battery can deliver 25A and maintain a minimum terminal voltage of 10.5V at 26.7° C(80° F)

PREHEATING SYSTEM

Item		Specifications
Glow plug	Rated voltage	DC 11V
	Current	16A \pm 1.5A after 4 seconds loading at rated voltage
Glow plug relay	Rated voltage	DC 12V
	Operating voltage range	DC 9V ~ DC 16V
	Operating temperature range	-40°C ~ 120°C
	Rated load current	DC 12V, 70A

AUTO CRUISE CONTROL SYSTEM

Items	Specification
Setting error	Within \pm 1.5Km/h on level road
Vehicle speed memory variation	No variation
Setting time	0.1sec max.
Resuming time	0.1sec max.
Minimum operating speed	40 \pm 2Km/h
Cancel speed range	15 \pm 2Km/h
Maximum memorized speed	160 \pm 2Km/h
Pulling force	127N(13Kgf)
Main switch serial resistance value	3.9k Ω \pm 1%
Command switch serial resistance value	SET switch : 220 Ω \pm 1%
	RESUME switch : 910 Ω \pm 1%

TIGHTENING TORQUE

Items	Nm	kg-cm	lb-ft
Generator terminal (B+)	5 ~ 7	50 ~ 70	3.6 ~ 5.1
Starter motor terminal (B+)	10 ~ 12	100 ~ 120	7.3 ~ 8.8
Battery terminal	4 ~ 6	40 ~ 60	2.9 ~ 4.3
Glow plug	15 ~ 20	150 ~ 200	11 ~ 15
Glow plug plate attaching nut	0.8 ~ 1.5	8 ~ 15	0.6 ~ 1.1

TROUBLESHOOTING

E23DF8A6

CHARGING SYSTEM

Symptom	Suspect Area	Remedy
Charging warning indicator does not light with ignition switch "ON" and engine off	Fuse blown Light burned out Wiring connection loose Electronic voltage regulator	Check fuses Replace light Tighten loose connections Replace voltage regulator
Charging warning indicator does not go out with engine running (Battery requires frequent recharging)	Drive belt loose or worn Battery cables loose, corroded or worn Fuse blown Fusible link blown Electronic voltage regulator or generator Wiring	Adjust tension or replace drive belt Repair or replace cables Check fuses Replace fusible link Test generator Repair wiring
Engine hesitates/poor acceleration Overcharge	Drive belt loose or worn Wiring connection loose or open circuit Fusible link blown Poor grounding Electronic voltage regulator or generator Worn battery Electronic voltage regulator Voltage sensing wire	Adjust tension or replace drive belt Tighten loose connection or repair wiring Replace fusible link Repair Test generator, if faulty, repair or replace Replace battery Replace voltage regulator Repair wire

STARTING SYSTEM

Symptom	Suspect Area	Remedy
Engine will not crank	Battery charge low Battery cables loose, corroded or worn out Transaxle range switch (Vehicle with automatic transaxle only) Fusible link blown Starter motor faulty Ignition switch faulty	Charge or replace battery Repair or replace cables Adjust or replace switch Replace fusible link Repair starter motor Inspect
Engine cranks slowly	Battery charge low Battery cables loose, corroded or worn out Starter motor	Charge or replace battery Repair or replace cables Repair starter motor
Starter keeps running	Starter motor Ignition switch	Repair starter motor Inspect
Starter spins but engine will not crank	Short in wiring Pinion gear teeth broken or starter motor Ring gear teeth broken	Repair wiring Repair starter motor Replace flywheel ring gear or torque converter

CRUISE CONTROL SYSTEM

**NOTE**

Before troubleshooting :

- Check the ECM(10A), Horn(10A), ECU #3(10A) and ECU B+(15A) fuse in the under - hood fuse/relay box.
- Check that the horn sounds.
- Check the tachometer to see if it works properly.

Symptom	Suspect Area	See Page
Cruise control cannot be set	Remocon switch Brake switch A/T gear position switch Cruise control unit	See page EE-34 See page EE-35 See page TR group-automatic transaxle See page EE-6
Cruise control cannot be set but indicator light does not go on	Dimming circuit in gauge Cruise control unit	See page EE-6 See page EE-6
Cruise speed is noticeably higher or lower than what was set	Vehicle speed sensor Cruise control unit and actuator cable deflection Cruise control unit	See page TR group-automatic transaxle See page EE-35 See page EE-6
Excessive overshooting or undershooting when trying to set speed	Cruise control unit and actuator cable deflection Vehicle speed sensor Cruise control unit	See page EE-35 See page TR group-automatic transaxle See page EE-6
Speed fluctuation on a flat road with cruise control set	Vehicle speed sensor Cruise control unit and actuator cable deflection Cruise control unit	See page TR group-automatic transaxle See page EE-35 See page EE-6
Vehicle does not decelerate or accelerate accordingly when SET/RESUME/CANCEL button is pushed	Remocon switch Cruise control unit	See page EE-34 See page EE-6
Cruise control does not cancel when shift lever is moved to N position (A/T)	A/T gear position switch Cruise control unit	See page TR group-automatic transaxle See page EE-6
Set speed is not cancelled when brake pedal is pushed	Brake switch Cruise control unit	See page EE-35 See page EE-6
Cruise control will not cancel when main switch is pushed OFF	Remocon switch Cruise control unit	See page EE-34 See page EE-6
Cruise control will not cancel when CANCEL button is pushed	Remocon switch Cruise control unit	See page EE-34 See page EE-6
Set speed will not resume when RESUME button (with main switch on, when set speed is temporarily cancelled)	Remocon switch Cruise control unit	See page EE-34 See page EE-6
The transmission shifts down slower than normal when going up a hill with the cruise control on (A/T)	Troubleshooting the cruise control communication circuit	See page EE-6

CRUISE CONTROL COMMUNICATION CIRCUIT
TROUBLESHOOTING (A/T)

- 1. Start the engine.
- 2. Turn on the cruise control main switch, then drive the vehicle to speeds over 25 mph (40km/h) with the cruise control.

Does the cruise control operate ?

YES - Go to step 3.


NO - Check the cruise control unit or cruise control actuator.

- 3. Measure the voltage between the O/D control terminal of the cruise control unit connector and ground.

Is there approx. 1V?


YES - Go to step 4.

NO - Replace the cruise control unit.



LBIF001A

- 4. Measure the voltage between the cruise control terminal of the TCM(or PCM) connector and ground.



LBIG001A

Is there approx. 1V?


YES - Check for loosen connectors. If necessary replace the TCM and recheck. (See Page TR group-automatic transaxle)

NO - Repair short or open in the wire between the TCM (or PCM) terminal and cruise control unit.

CHARGING SYSTEM

DESCRIPTION EDCABFCE

The conventional internal voltage detection type alternator controls the charging voltage regardless of the battery condition and according to the external load change so that it sometimes causes battery under or over charging or causes flickering of meters and lamps due to ripples of generated voltage resulting from load fluctuation. The figure below show the internal circuits of the alternator and voltage regulator.



LBIF018A

ON-VEHICLE INSPECTION EE8EC6C0

CAUTION

- **Check that the battery cables are connected to the correct terminals.**
- **Disconnect the battery cables when the battery is given a quick charge.**
- **Do not perform tests with a high voltage insulation resistance tester.**
- **Never disconnect the battery while the engine is running.**

CHECK BATTERY VOLTAGE

1. After having driven the vehicle and in the case that 20 minutes have not passed after having stopped the engine, turn the ignition switch ON and turn on the electrical system (headlamp, blower motor, rear defogger etc.) for 60 seconds to remove the surface charge.
2. Turn the ignition switch OFF and turn off the electrical systems.
3. Measure the battery voltage between the negative (-) and positive (+) terminals of the battery.

Standard voltage : 12.5~12.9V at 20°C (68°C)

If the voltage is less than specification, charge the battery.

CHECK BATTERY TERMINALS, FUSIBLE LINK AND FUSES


1. Check that the battery terminals are not loose or corroded.
2. Check the fusible link and fuses for continuity.

INSPECT DRIVE BELT

1. Visually check the belt for excessive wear, frayed cords etc.
If any defect has been found, replace the drive belt.

**NOTE**

Cracks on the rib side of a belt are considered acceptable. If the belt has chunks missing from the ribs, it should be replaced.



LBIF019A

2. Using a belt tension gauge, measure the drive belt tension.

VISUALLY CHECK ALTERNATOR WIRING AND LISTEN FOR ABNORMAL NOISES

1. Check that the wiring is in good condition.
2. Check that there is no abnormal noise from the alternator while the engine is running.

CHECK DISCHARGE WARNING LIGHT CIRCUIT

1. Warm up the engine and then turn it off.
2. Turn off all accessories.
3. Turn the ignition switch "ON". Check that the discharge warning light is on.
4. Start the engine. Check that the light goes off.

If the light does not go off as specified, troubleshoot the discharge light circuit.

INSPECT CHARGING SYSTEM

VOLTAGE DROP TEST OF ALTERNATOR OUTPUT WIRE

This test determines whether or not the wiring between the alternator "B" terminal and the battery (+) terminal is good by the voltage drop method.


PREPARATION

1. Turn the ignition switch to "OFF".

**NOTE**

To find abnormal conditions of the connection, actions should not be taken on the two terminals and each connection during the test.

2. Connect a digital voltmeter between the alternator "B" terminal and battery (+) lead wire to the battery (+) terminal. Connect the (+) lead wire of the voltmeter to the "B" terminal and the (-) lead wire to the battery (+) terminal.



LBIF022A

CONDITIONS FOR THE TEST

1. Start the engine.
2. Switch on the headlamps, blower motor and so on. And then, read the voltmeter under this condition.

RESULT

1. The voltmeter may indicate the standard value.

Standard value: 0.2V max.

2. If the value of the voltmeter is higher than expected (above 0.2V max.), poor wiring is suspected. In this case check the wiring from the alternator "B" terminal to the fusible link to the battery (+) terminal. Check for loose connections, color change due to an overheated harness, etc. Correct them before testing again.
3. Upon completion of the test, set the engine speed at idle. Turn off the head lamps, blower motor and the ignition switch.

OUTPUT CURRENT TEST

This test determines whether or not the alternator gives an output current that is equivalent to the nominal output.


PREPARATION

1. Prior to the test, check the following items and correct as necessary.
Check the battery installed in the vehicle to ensure that it is in good condition. The battery checking method is described in "BATTERY".
The battery that is used to test the output current should be one that has been partially discharged. With a fully charged battery, the test may not be conducted correctly due to an insufficient load.
Check the tension of the alternator drive belt.
2. Turn off the ignition switch.
3. Disconnect the battery ground cable.
4. Disconnect the alternator output wire from the alternator "B" terminal.
5. Connect a DC ammeter (0 to 150A) in series between the "B" terminal and the disconnected output wire. Be sure to connect the (-) lead wire of the ammeter to the disconnected output wire.

NOTE

Tighten each connection securely, as a heavy current will flow. Do not rely on clips.

6. Connect a voltmeter (0 to 20V) between the "B" terminal and ground. Connect the (+) lead wire to the alternator "B" terminal and (-) lead wire to a good ground.
7. Attach an engine tachometer and connect the battery ground cable.
8. Leave the engine hood open.



LBIF023A

TEST

1. Check to see that the voltmeter reads as the same value as the battery voltage. If the voltmeter reads 0V, and the open circuit in the wire between the alternator "B" terminal and battery (-) terminal, a blown fusible link or poor grounding is suspected.
2. Start the engine and turn on the headlights.
3. Set the headlights to high beam and the heater blower switch to HIGH, quickly increase the engine speed to 2,500 rpm and read the maximum output current value indicated by the ammeter.

NOTE

After the engine starts up, the charging current quickly drops. Therefore, the above operation must be done quickly to read the maximum current value correctly.

RESULT

1. The ammeter reading must be higher than the limit value. If it is lower but the alternator output wire is in good condition, remove the alternator from the vehicle and test it.

Limit value (90A alternator): 63A min.

NOTE

- The nominal output current value is shown on the nameplate affixed to the alternator body.
- The output current value changes with the electrical load and the temperature of the alternator itself. Therefore, the nominal output current may not be obtained. If such is the case, keep the headlights on the cause discharge of the battery, or use the lights of another vehicle to increase the electrical load.

The nominal output current may not be obtained if the temperature of the alternator itself or ambient temperature is too high.

In such a case, reduce the temperature before testing again.


3. Upon completion of the output current test, lower the engine speed to idle and turn off the ignition switch.
4. Disconnect the battery ground cable.
5. Remove the ammeter and voltmeter and the engine tachometer.
6. Connect the alternator output wire to the alternator "B" terminal.
7. Connect the battery ground cable.

REGULATED VOLTAGE TEST

The purpose of this test is to check that the electronic voltage regulator controls voltage correctly.

PREPARATION

1. Prior to the test, check the following items and correct if necessary.
Check that the battery installed on the vehicle is fully charged. For battery checking method, see "BATTERY".
Check the alternator drive belt tension.
2. Turn ignition switch to "OFF".
3. Disconnect the battery ground cable.
4. Connect a digital voltmeter between the "B" terminal of the alternator and ground. Connect the (+) lead of the voltmeter to the "B" terminal of the alternator. Connect the (-) lead to good ground or the battery (-) terminal.
5. Disconnect the alternator output wire from the alternator "B" terminal.
6. Connect a DC ammeter (0 to 150A) in series between the "B" terminal and the disconnected output wire. Connect the (-) lead wire of the ammeter to the disconnected output wire.
7. Attach the engine tachometer and connect the battery ground cable.



LBIF024A

RESULT

1. If the voltmeter reading agrees with the value listed in the Regulating Voltage Table below, the voltage regulator is functioning correctly. If the reading is other than the standard value, the voltage regulator or the alternator is faulty.

REGULATING VOLTAGE TABLE

Voltage regulator ambient temperature °C (°F)	Regulating voltage (V)
-30 (-22)	14.1 ~ 15.2
20 (68)	14.1 ~ 14.7
120 (248)	13.3 ~ 14.7

2. Upon completion of the test, reduce the engine speed to idle, and turn off the ignition switch.
3. Disconnect the battery ground cable.
4. Remove the voltmeter and ammeter and the engine tachometer.
5. Connect the alternator output wire to the alternator "B" terminal.
6. Connect the battery ground cable.

TEST

1. Turn on the ignition switch and check to see that the voltmeter indicates the following value.

Voltage: Battery voltage

If it reads 0V, there is an open circuit in the wire between the alternator "B" terminal and the battery and the battery (-), or the fusible link is blown.


2. Start the engine. Keep all lights and accessories off.
3. Run the engine at a speed of about 2,500 rpm and read the voltmeter when the alternator output current drops to 10A or less.

ALTERNATOR

REPLACEMENT


EB1AECC9

1. Disconnect the battery negative terminal first, then the positive terminal.
2. Disconnect the alternator connector(A) and "B" terminal cable(B) from the alternator(C).
3. Disconnect the vacuum pump oil drain hose(D), vacuum pump oil feed hose(E) and vacuum hose(F).



SJMEM6001D


4. Remove the mounting bolt(A) and through bolt(B), then remove the alternator(C).



LBIF030A

5. Installation is the reverse of removal.

COMPONENTS E7BABA5C




1. Pulley cover
2. Pulley
3. Front frame
4. Front bearing
5. Bearing cover
6. Bolts

7. Rotor
8. Stator
9. Brush & Regulator assembly
10. Rear frame
11. Throught bolts
12. Vacuum pump


DISASSEMBLY ECB8FF64

1. Remove the pulley cover.
2. Remove the pulley(A) using the special tool(B).




LBIF048A

3. After loosening the three bolts(A), remove the vacuum pump(B).




LBIF049A

4. Remove the B terminal insulator(A) and loosen the five rear cover mounting nuts(B).




LBIF050A

5. After loosening the four through bolts(A), remove the rear cover(B).




LBIF051A

6. After removing the weld between the stator lead and diode lead(A), remove the regulator assembly(B).



LBIF052A

7. Separate the rotor(A), stator(B), and front cover(C).



LBIF053A


8. Installation is the reverse of removal.

INSPECTION

E00B85EA

INSPECT ROTOR

1. Check that there is continuity between the slip rings(A).




LBIF054A

2. Check that there is no continuity between the slip rings and the rotor(B) or rotor shaft(C).
3. If the rotor fails either continuity check, replace the alternator.

INSPECT STATOR

1. Check that there is continuity between each pair of leads(A).




LBIF055A

2. Check that there is no continuity between each lead and the coil core.
3. If the coil fails either continuity check, replace the generator.

BATTERY

DESCRIPTION ECBDB3EF


1. The maintenance-free battery is, as the name implies, totally maintenance free and has no removable battery cell caps.
2. Water never needs to be added to the maintenance-free battery.
3. The battery is completely sealed, except for small vent holes in the cover.



LBIF059A

INSPECTION EF4DE1EC

CHECKING PROCEDURE OF BATTERY



CHECKING SHEET

Inspection Items & contents	Judgment criteria	Responsibility		Remarks
		User	Manufacturer	
1. Acid Leakage * Type of acid leakage - Leakage on the fusion part for joining the case and cover. - Leakage on the terminal part - Leakage on the other parts * Clean the wet part or wash it, then dry it before checking with naked eyes. * Determine a part where leakage might have occurred ; check it by tipping the battery, if the leakage takes place again. * Conduct a visual inspection for breakage, deformation, or cracks.	1. Damage in the case or cover due to outside impact.			
	2. Acid leakage on the molding part of the case or cover. (weld line or gate hole)			
	3. Damage on the terminal or cracks in the cover.			
	4. Acid leakage due to the tipped battery or slant storage.			
	5. Acid leakage due to poor welding of the cover. (with no damage)			
2. Outside damage and breakage * Check with naked eyes.	1. Outside damage due to causes without damage due to mistreatment.			
	2. Outside damage due to mistreatment.			
	3. Damage due to a spark between terminals.			
	4. Damage and breakage due to heat.			
3. Measure the voltage for the battery ; but wait at least one day before measuring in case of recharging, and recharging should be made in accordance with the charging instructions.	1. 12.0V			Refer to load test
	2. 11.0V< battery voltage<12.0V due to over-discharge.			Refer to load test
	3. Below 11.0V due to charge condition failure.			Refer to load test
	4. Below 11.0V due to discharged for a long period.			Refer to load test
	5. Below 11.0V due to internal short circuit.			Refer to load test
4. Load test ; For 15 seconds with a half of the CCA electric current value, but the voltage on the discharging stage should be above 9.6V (27±5°C) - Conduct the test with a battery tester. (Refer to the tester manual)	1. Load test result: below 9.5V			
	2. Load test result: above 9.6V			Mfg. Defect usable

LOAD TEST

1. Perform the following steps to complete the load test procedure for maintenance free batteries.
2. Connect the load tester clamps to the terminals and proceed with the test as follow :
 - a. If the battery has been on charge, remove the surface charge by connect a 300 ampere load for 15 seconds.
 - b. Connect the voltmeter and apply the specified load.
 - c. Read the voltage after the load has been applied for 15 seconds.
 - d. Disconnect the load.
 - e. Compare the voltage reading with the minimum and replace the battery if battery test voltage is below that shown in the voltage table.

Voltage	Temperature
9.6	20°C (70°F) and above
9.5	16 °C (60 °F)
9.4	10 °C (50 °F)
9.3	4 °C (40 °F)
9.1	-1 °C (30 °F)
8.9	-7 °C (20 °F)
8.7	-12 °C (10 °F)
8.5	-18 °C (0 °F)

**NOTE**


- If the voltage is less than shown in the table, the battery is good.
- If the voltage is greater than shown in the table, replace the battery.

BATTERY DIAGNOSTIC TEST

1. Make sure the ignition switch and all accessories are in the OFF position.
2. Disconnect the battery cables (negative first).
3. Remove the battery from the vehicle.

**CAUTION**

Care should be taken in the event the battery case is cracked or leaking, to protect your skin from the electrolyte. Heavy rubber gloves (not the household type) should be worn when removing the battery.




LBIF061A

4. Inspect the battery carrier for damage caused by the loss of electrolyte. If acid damage is present, it will be necessary to clean the area with a solution of clean warm water and baking soda. Scrub the area with a stiff brush and wipe off with a cloth moistened with baking soda and water.
5. Clean the top of the battery with the same solution as described in Step(3).
6. Inspect the battery case and cover for cracks. If cracks are present, the battery must be replaced.
7. Clean the battery posts with a suitable battery post tool.
8. Clean the inside surface of the terminal clamps with a suitable battery cleaning tool. Replace damaged or frayed cables and broken terminal clamps.
9. Install the battery in the vehicle.
10. Connect the cable terminals to the battery post, making sure the tops of the terminals are flush with the tops of the posts.

11. Tighten the terminal nuts securely.
12. Coat all connections with light mineral grease after tightening.

**CAUTION**

When batteries are being charged, an explosive gas forms beneath the cover of each cell. Do not smoke near batteries being charged or which have recently been charged. Do not break live circuits at the terminals of batteries being charged. A spark will occur when the circuit is broken. Keep open flames away from the battery.



LBIF059A

STARTING SYSTEM


DESCRIPTION EFE0D698

The starting system includes the battery, starter motor, solenoid switch, ignition switch, inhibitor switch(A/T), ignition lock switch, connection wires and the battery cable.

When the ignition key is turned to the start position, current flows and energizes the starter motor's solenoid coil.

The solenoid plunger and clutch shift lever are activated, and the clutch pinion engages the ring gear.

The contacts close and the starter motor cranks. In order to prevent damage caused by excessive rotation of the starter armature when the engine starts, the clutch pinion gear overruns.



LBIF063A

INSPECTION E44C2FBC

START TEST



NOTE

The air temperature must be between 59 and 100°F (15 and 38°C) before testing.

Recommended procedure :

- Use a starter system tester.
- Connect and operate the equipment in accordance with the manufacturer's instructions.
- Test and troubleshoot as described.

Alternate Procedure :

- Use the following equipment :
 - Ammeter, 0~400A
 - Voltmeter, 0~20V (accurate within 0.1 volt)
 - Tachometer, 0~1,200 rpm
- Hook up a voltmeter and ammeter as shown.



NOTE

After this test, or any subsequent repair, reset the ECM/PCM to clear any codes.

Check the Starter Engagement :

1. Remove the ECM(B+) fuse from the fuse/relay box.
2. Turn the ignition switch to START (III) with the shift lever in N or P position (A/T) or with the clutch pedal depressed (M/T). The starter should crank the engine.
 - If the starter does not crank the engine, go to step 3.
 - If it cranks the engine erratically or too slowly, go to "Check for Wear and Damage" on the next page.
3. Check the battery, battery positive cable, ground, starter cut relay, and the wire connections for looseness and corrosion. Test again.
If the starter still does not crank the engine, go to step 4.
4. Unplug the connector from the starter.
5. Connect a jumper wire from the battery positive (+) terminal to the solenoid terminal.
The starter should crank the engine.
 - If the starter still does not crank the engine, remove it, and diagnose its internal problem.
 - If the starter cranks the engine, go to step 6.
6. Check the ignition switch.
7. Check the starter relay.

8. Check the A/T gear position switch (A/T) or the clutch interlock switch (M/T).
9. Check for an open in the wire between the ignition switch and starter.


CHECK FOR WEAR AND DAMAGE

The starter should crank the engine smoothly and steadily. If the starter engages, but cranks the engine erratically, remove it, and inspect the starter drive gear and torque converter ring gear for damage.

Check the drive gear overrunning clutch for binding or slipping when the armature is rotated with the drive gear held. If damaged, replace the gears.


STARTER SOLENOID TEST

1. Disconnect the wires from the S terminal and the M terminal.
2. Connect the battery as shown. If the starter pinion pops out, it is working properly. To avoid damaging the starter, do not leave the battery connected for more than 10 seconds.




LBIF065A

3. Disconnect the battery from the M terminal. If the pinion does not retract, the hold-in coil is working properly. To avoid damaging the starter, do not leave the battery connected for more than 10 seconds.



LBIF066A

4. Disconnect the battery also from the body. If the pinion retracts immediately, it is working properly. To avoid damaging the starter, do not leave the battery connected for more than 10 seconds.




LBIF067A

FREE RUNNING TEST

1. Place the starter motor in a vise equipped with soft jaws and connect a fully-charged 12-volt battery to starter motor as follows :
2. Connect a test ammeter (100-ampere scale) and carbon pile rheostat as shown in the illustration.
3. Connect a voltmeter (15-volt scale) across starter motor.
4. Rotate carbon pile to the off position.
5. Connect the battery cable from battery's negative post to the starter motor body.
6. Adjust until battery voltage shown on the voltmeter reads 11 volts.
7. Confirm that the maximum amperage is within the specifications and that the starter motor turns smoothly and freely :

Current : Max. 120 Amps

Speed : Min. 4,000 rpm



LBIF068A

CLEANING


E8C3711A

1. Do not immerse parts in cleaning solvent. Immersing the yoke assembly and/or armature will damage the insulation. Wipe these parts with a cloth only.
2. Do not immerse the drive unit in cleaning solvent. The overrun clutch is pre-lubricated at the factory and solvent will wash lubrication from the clutch.
3. The drive unit may be cleaned with a brush moistened with cleaning solvent and wiped dry with a cloth.

STARTER

REPLACEMENT E1BE77DD

1. Disconnect the battery negative cable.
2. Disconnect the starter cable(A) from the B terminal(B) on the solenoid(C), then disconnect the connector(D) from the S terminal(E).




LBIG001B

3. Remove the 2 bolts holding the starter, then remove the starter.
4. Installation is the reverse of removal.
5. Connect the battery positive cable and negative cable to the battery.

COMPONENTS

EBAF73D6




1. Front bracket
2. Overrun clutch assembly
3. Idle gear
4. Driver gear
5. Idle gear bearing
6. Housing
7. Spring

8. Magnetic switch
9. Packing
10. Rear cover
11. Brush holder
12. Packing
13. Yoke assembly


DISASSEMBLY E8534E61

1. Remove the nut(A) and disconnect the lead wire(B) from the magnetic switch terminal(C).



LBIF085A

2. Remove the 2 bolts(A) and pull out the yoke assembly(B) with the armature(C) from the front bracket(D).




LBIF086A

3. Using a screwdriver, hold the spring tank back and disconnect the brush(A) from the brush holder(B). Disconnect the 2 brushes and remove the brush holder.


**NOTE**

Check that the positive(+) lead wires are not grounded.




LBIF087A

4. Remove the 3 screws(A) and disconnect the housing rear cover(B) and packing(C).




LBIF088A

5. Remove the magnetic switch(A) and spring coil(B).




LBIF089A

6. Remove the 2 screws(A) and disconnect the clutch sub assembly(B), idle gear(C), idle gear bearing(D) and drive gear(E) from the housing(F).



LBIF090A

7. Using a magnetic finger(A), remove the steel ball(B) from the clutch shaft hole.




LBIF091A

8. Reassembly is the reverse of disassembly.



NOTE

When installing the yoke assembly(A), use a new O-ring(B) and align the mark(C) on the housing to the mark(D) range of the brush holder.




LBIF092A

INSPECTION

E712D053

ARMATURE INSPECTION AND TEST

1. Remove the starter (see page EE-25).
2. Disassemble the starter as shown at the beginning of this procedure.
3. Inspect the armature for wear or damage from contact with the permanent magnet. If there is wear or damage, replace the armature.




LBIF093A

4. Measure the commutator (A) runout.
 - If the commutator runout is within the service limit, check the commutator for carbon dust or brass chips between the segments.
 - If the commutator runout is not within the service limit, replace the armature.

Commutator Runout


Standard (New) : 0.02mm (0.001 in.) max.

Service limit : 0.05mm (0.002 in.)




LBIF094A

5. Check for continuity between the segments of the commutator. If an open circuit exists between any segments, replace the armature.



LBIF095A


6. Check with an ohmmeter that no continuity exists between the commutator (A) and armature coil core (B), and between the commutator and armature shaft (C). If continuity exists, replace the armature.



LBIF096A

INSPECT STARTER BRUSH


Brushes that are worn out, or oil-soaked, should be replaced.



LBIF097A

STARTER BRUSH HOLDER TEST


Check that there is no continuity between the (+) brush holder (A) and (-) brush holder (B). If there is no continuity, replace the brush holder assembly.



LBIF098A

INSPECT OVERRUNNING CLUTCH

1. Slide the overrunning clutch along the shaft. Replace it if does not slide smoothly.
2. Rotate the overrunning clutch (A) both ways. Does it lock in one direction and rotate smoothly in reverse? If it does not lock in either direction or it locks in both directions, replace it.




LBIF099A

3. If the starter driver gear (B) is worn or damaged, replace the overrunning clutch assembly: the gear is not available separately. Check the condition of the flywheel or torque converter ring gear if the starter drive gear teeth are damaged.

STARTER RELAY



INSPECTION E03A96B5

1. Remove the fuse box cover.
2. Remove the starter relay(A).



AVIE004A

3. Inspect the relay continuity.
 - Using an ohmmeter, check that there is continuity between terminals 85 and 86.
If there is no continuity, replace the relay.
 - Check that there is no continuity between terminals 30 and 87.
If there is continuity, replace the relay.
4. Inspect the relay operation.
 - Apply battery positive voltage across terminals 85 and 86.
 - Using an ohmmeter, check that there is continuity between terminals 30 and 87.
If there is no continuity, replace the relay.





LDAD510B

5. Install the starter relay.
6. Install the fuse box cover.

CRUISE CONTROL SYSTEM

COMPONENTS LOCATION EF26FAE8




- 1. Cruise control indicator
- 2. Main switch
- 3. Brake switch

- 4. Actuator & unit assembly
- 5. Actuator cable

CIRCUIT DIAGRAM FOR CRUISE CONTROL SYSTEM


ECC73F72



INSPECTION E03C058C

CRUISE REMOCON SWITCH TEST

- 1. Disconnect the battery negative cable, then disconnect the positive cable, and wait at least three minutes.
- 2. Remove the driver's airbag (See page RT group-air bag module).
- 3. Disconnect the remocon switch connector(A).




LBIF105A

- 4. Check the continuity between the terminals of the connector in each switch position according to the table.
 - If there is continuity, and it matches the table, the switch is O.K.
 - If there is no continuity, replace the remocon switch.

Terminal Position	1	2	3	4
MAIN (ON)				
SET (ON)				
RESUME (ON)				
CANCEL (ON)				

LBIF062A




CIRCUIT DIAGRAM

LBIF106A

BRAKE SWITCH TEST

- 1. Disconnect the connector(A) from the brake switch.
- 2. Remove the brake switch(B).



LBIF107A

- 3. Check for continuity between the terminals according to the table.

Position \ Terminal	Terminal			
	1	2	3	4
Depressed		○ — ○		
Released	○ —			○


LBIF121A

- 4. If necessary, replace the switch or adjust the pedal height.

REPLACEMENT E1C22A98


CRUISE CONTROL UNIT AND CABLE

- 1. Loosen the locknuts(A) and disconnect the actuator cable (B) from the throttle linkage(C).




LBIF108A

- 2. Disconnect the cover, actuator cable and connector.



LBIF109A

3. Loosen the three mounting bolts(E), and remove the actuator(F) with the bracket.




LBIF110A

4. Installation is the reverse of removal.

CRUISE REMOCON SWITCH REPLACEMENT

1. Disconnect the battery negative cable, then disconnect the positive cable, and wait at least three minutes.
2. Remove the driver's airbg (See page RT group-air bag module).
3. Disconnect the remocon switch connector(A).
4. Loosen the two mounting screws(B), and remove the cruise remocon switch(C).




LBIF111A

5. Installation is the reverse of removal.
6. Connect the battery positive cable and negative cable to the battery.

ACTUATOR CABLE ADJUSTMENT


E3E12C8D

1. Check that the actuator cable (A) moves smoothly with no binding or sticking.




LBIF112A

2. Start the engine. Hold the engine at 3,000 rpm with no load (A/T in **N** or **P** position, M/T in neutral) until the radiator fan comes on, then let it idle.
3. Measure the amount of movement of the output linkage (B) until the engine speed starts to increase. At first, the output linkage should be located at the fully closed position (C). The free play (D) should be 3.75 ± 0.5 mm (0.15 ± 0.02 in.).
4. If the free play is not within specs, move the cable to the point where the engine speed starts to increase, and tighten the locknut (A) and adjusting nut (B).




LBIF113A

5. Turn the adjusting nut (A) until it is 3.75 ± 0.5 mm (0.15 ± 0.02 in.) away from the bracket (B).



LBIF114A


6. Pull the cable so that the adjusting nut (A) touches the bracket, and tighten the locknut (B).



LBIF115A

PREHEATING SYSTEM

COMPONENTS LOCATION E64278AC



- 1. Glow relay
- 2. Glow plug connector

- 3. Glow plug
- 4. Plate

INSPECT PREHEATING SYSTEM

E812E6A0

Conditions before inspection :


Battery voltage : 12V

1. Connect voltmeter between glow plug plate and plug body (ground).
2. Check indicated value on voltmeter with ignition switch ON.
3. Check that preheat indication lamp lights for about 6 seconds and indicates battery voltage (about 9V or over) for about 36 seconds immediately after ignition-switch is turned on. [At cooling water temperature 20°C (68°F)]

**NOTE**

Continuity time varies depending upon cooling water temperature.

4. After checking 3, set ignition switch at START position.
5. The system is normal if battery voltage (about 9V or over) is generated for about 6 seconds during engine cranking and after start operation. [at cooling water temperature 20°C (68°F)]
6. When the voltage or continuity time is not normal, check the terminal voltage in glow control unit, and single parts.



LBIF117A

INSPECT GLOW PLUS


1. Check the continuity between the terminal and body as illustrated. Replace if discontinuity or with large resistance.

Standard value : 0.25Ω

**CAUTION**

Remove oil from plug before measuring as glow plug resistance is very small.


2. Check for rust on glow plug plate.
3. Check glow plug for damage.




LBIF118A

INSPECT GLOW PLUG RELAY

1. Remove the glow plug relay.
2. Inspect the relay continuity.
 - Using an ohmmeter, check that there is continuity between terminals 2 and 4.
If there is no continuity, replace the relay.
 - Check that there is no continuity between terminals 1 and 5.
If there is continuity, replace the relay.
3. Inspect the relay operation.
 - Apply battery positive voltage across terminals 2 and 4.
 - Using an ohmmeter, check that there is continuity between terminals 1 and 5.
If there is no continuity, replace the relay.



LBIF119A



LBIF120A

4. Install the glow plug relay.