



- C 2 Fuel Injector Assembly No. 2
- C 4 Fuel Injector Assembly No. 4
- C 7 Ignition Coil Assembly No. 1
- C 8 Ignition Coil Assembly No. 2
- C 9 Ignition Coil Assembly No. 3
- C 10 Ignition Coil Assembly No. 4
- C 13 Throttle Body Assembly
- C 15 Purge VSV
- C 24 E.F.I. Engine Coolant Temperature Sensor
- C 27 Oxygen Sensor (Bank 1 Sensor 2)
- C 33 Intake Mass Air Flow Meter Sub-Assembly
- C 38 Vane Pump Assembly
- C 39 Cooler Compressor Assembly
- C 41 Back-Up Light Switch Assembly
- C 42 Engine Oil Pressure Switch Assembly
- C 43 Transfer Shift Actuator Assembly
- C 50 Fuel Injector Assembly No. 1
- C 51 Fuel Injector Assembly No. 3
- C 52 Cam Position Sensor
- C 53 Crank Position Sensor
- C 54 Cam Timing Oil Control Valve (Bank 1)
- C 55 Air Switching Valve Assembly
- C 56 Air Fuel Ratio Sensor (Bank 1 Sensor 1)
- C 57 Power Steering Oil Pressure Switch
- C 65 Generator Assembly
- C 67 Generator Assembly
- C 68 Noise Filter (Ignition)
- C 95 Starter Assembly

- D 4 Starter Assembly

- h 3 Knock Control Sensor (Bank 1)

- p 1 Front Speed Sensor RH
- p 2 Front Speed Sensor LH

