


Position of Parts in Body <LHD>



S 17 Scuff Plate Light Front LH
S 18 Scuff Plate Light Front RH
S 19 Scuff Plate Light Rear LH
S 20 Scuff Plate Light Rear RH
S 21 Side Airbag Sensor Front LH
S 22 Side Airbag Sensor Front RH
S 23 Side Airbag Sensor Rear LH
S 24 Side Airbag Sensor Rear RH
S 25 Speed Sensor Rear LH
S 26 Speed Sensor Rear RH
S 27 Stereo Component Amplifier
S 28 Stereo Component Amplifier
S 29 Stereo Component Amplifier
S 30 Stereo Component Amplifier
S 31 Stop Light LH
S 32 Stop Light RH
S 35 Stereo Component Amplifier
S 36 Stereo Component Amplifier
S 37 Stereo Component Amplifier
S 38 Stereo Component Amplifier


T 12 Taillight LH
T 13 Taillight RH
T 14 Television Camera
T 16 Television Camera ECU
T 17 Television Camera ECU
T 18 Theft Deterrent Siren
T 19 Television Camera ECU
T 20 Television Camera ECU

V 10 Vanity Light LH
V 11 Vanity Light RH

W 2 Woofer (Front LH)
W 3 Woofer (Front RH)

Y 1 Yaw Rate Sensor

Position of Parts in Body <LHD>



Y 1
Black

