
(BAT)
10A ECU-B
(BAT)
25A MAIN NO. 2
(ACC)
7.5A ACC
(IG)
20A ECU-IG NO. 2
G63(A), G64(B) Main Body ECU
IG
ACC
ALTB
BECU
GND2
GND1
CLTE
CLTS
CLTB
K13 Automatic Light Control Sensor
TAIL
HEAD
HU
HF
HRLY
DIM
G44(A), (B) Headlight Dimmer Switch Assembly
Light Control Switch
Dimmer Switch
EL
A
T
H
DRL OFF (*1 *2) OFF (*3) OFF (*3 *4)
Tail
Head
AUTO
ED
Flash
Low
High
* 1 : Headlight Dimmer Switch Assembly LH Side Type
* 2 : Headlight Dimmer Switch Assembly RH Side Type
* 3 : w/ Daytime Running Light
* 4 : w/o Daytime Running Light
* 8 : HID Type
* 9 : Except HID Type
25A HALP HI
15A HALP LO RH
15A HALP LO LH
15A HALP RH-HI
15A HALP LH-HI
Battery
Headlight Assembly RH
Headlight Assembly LH
Low Beam
High Beam
Auxiliary
Daytime Running Light
CANH
CANL
G39(A), G43(B) Junction Connector
G39(A), G43(B) Main Body ECU
* 5 : LHD 1GR-FE, LHD 1KD-FTV
* 7 : LHD 2TR-FE, LHD 5L-E
* 8 : HID Type
* 9 : Except HID Type
(BAT)
10A ECU-B
(IG)
7.5A GAUGE
ECU-B
Main
Power Supply Circuit
Micro-Computer
IG1
CANL
CANH
IG2
Combination Meter Assembly
A73(B), A73(A) Junction Connector
* 5 : LHD 1GR-FE, LHD 1KD-FTV
* 7 : LHD 2TR-FE, LHD 5L-E
*10 : 1GR-FE
*11 : 2TR-FE
*12 : 1KD-FTV
*13 : 5L-E
G39(A), G43(B) Junction Connector
G104 Junction Connector
G106 Junction Connector