



- * 7 : w/ Parking Assist (TOYOTA Parking Assist-Sensor) (4 Sensor Type)
- * 8 : w/o Parking Assist (TOYOTA Parking Assist-Sensor) (4 Sensor Type)
- * 9 : 5-Door
- *10 : 3-Door
- *11 : 1GR-FE
- *12 : 2TR-FE
- *13 : 1KD-FTV
- *14 : 5L-E