



- A 1 Fog Lamp (Front LH)
- A 2 Ambient Temp. Sensor
- A 3 Horn (High)
- A 4 Horn (Low)
- A 5 Engine Hood Courtesy SW
- A 8 Headlamp (LH High)
- A 9 Clearance Lamp (Front LH)
- A 10 Turn Signal Lamp (Front LH)
- A 13 Airbag Sensor (Front LH)
- A 14 Speed Sensor (Front LH)
- A 16 Brake Fluid Level Warning SW
- A 23 Security Horn
- A 24 Engine ECU
- A 26 Skid Control ECU with Actuator
- A 27 A/C Pressure Sensor
- A 28 Airbag Sensor (Front RH)
- A 29 Headlamp (RH High)
- A 30 Clearance Lamp (Front RH)
- A 31 Turn Signal Lamp (Front RH)
- A 34 Fog Lamp (Front RH)
- A 35 Speed Sensor (Front RH)
- A 37 Windshield Washer Motor
- A 38 Headlamp Cleaner Motor
- A 39 Headlamp Cleaner Control Relay
- A 43 Junction Connector
- A 44 Junction Connector
- A 45 Headlamp (LH Low)
- A 48 Wireless Door Lock Buzzer
- A 49 Headlamp (RH Low)
- A 53 VSV (Air Intake Control)
- A 54 Cooling Fan ECU
- A 59 Windshield Wiper Motor
- A 62 Ultrasonic Sensor (Front Corner RH)
- A 65 Headlamp Assembly (LH)
- A 66 Headlamp Assembly (RH)
- A 69 Ultrasonic Sensor (Front Corner LH)
- A 71 Headlamp Leveling Motor (LH)
- A 72 Headlamp Leveling Motor (RH)

Position of Parts in Engine Compartment <RHD 2GR-FE>



