



H 1 Speaker (Front Door RH)  
H 3 Outer Rear View Mirror (RH)  
H 7 Courtesy Lamp (Front Door RH)  
H 8 Door Lock Assembly (Front RH)  
H 10 Power Window ECU (Front RH)

I 1 Speaker (Front Door LH)  
I 2 Outer Rear View Mirror (LH)  
I 4 Power Window Regulator Motor (Front LH)  
I 6 Courtesy Lamp (Front Door LH)  
I 7 Door Lock Assembly (Front LH)  
I 9 Power Window SW (Front LH)

J 1 Power Window SW (Rear RH)  
J 3 Power Window Regulator Motor (Rear RH)  
J 5 Door Lock Assembly (Rear RH)  
J 6 Courtesy Lamp (Rear Door RH)

K 1 Power Window SW (Rear LH)  
K 3 Power Window Regulator Motor (Rear LH)  
K 5 Door Lock Assembly (Rear LH)  
K 6 Courtesy Lamp (Rear Door LH)

# Position of Parts in Body <RHD>

