


\* 7:w/ Navigation System  
 \* 8:w/o Navigation System



- F 1 Combination Meter
- F 2 Combination Meter
- F 3 Clock
- F 4 Hazard Warning Signal SW
- F 5 Glove Box Lamp
- F 6 Radio Receiver Assembly
- F 7 Radio Receiver Assembly
- F 8 Radio Receiver Assembly
- F 12 Navigation Receiver Assembly
- F 13 Navigation Receiver Assembly
- F 15 Antenna Amplifier
- F 16 A/C Control Assembly
- F 21 Tweeter (Front LH)
- F 23 Tweeter (Front RH)
- F 30 Clearance Warning Buzzer
- F 36 Navigation Receiver Assembly
- F 37 Navigation Receiver Assembly
- F 38 Navigation Receiver Assembly
- F 42 Navigation Receiver Assembly

Position of Parts in Instrument Panel <RHD>

