


Position of Parts in Body <LHD 5-Door>

- * 5:w/ Reading Light
- * 6:w/o Reading Light
- * 7:w/ Glass Hatch Opener
- * 8:w/o Glass Hatch Opener



- S 1 Rear Shock Absorber Assembly RH
- S 3 Rear Height Control Sensor Sub-Assembly RH
- S 4 Rear Shock Absorber Assembly LH
- S 5 Fuel Sender Gauge Assembly
- S 6 Rear Height Control Sensor Sub-Assembly LH
- S 7 Height Control Valve
- S 8 Fuel Pump Control ECU Assembly
- S 9 Fuel Pump Control ECU Assembly
- S 10 Height Control Exhaust Valve (Height Control Compressor)
- S 11 Height Control Compressor Motor (Height Control Compressor Assembly)


- U 1 Rear No. 1 Ultrasonic Sensor Center RH
- U 2 Rear No. 1 Ultrasonic Sensor RH
- U 3 Rear Fog Light Assembly RH

- V 1 Rear No. 1 Ultrasonic Sensor Center LH
- V 2 Rear No. 1 Ultrasonic Sensor LH
- V 3 Rear Fog Light Assembly LH

- W 1 Vanity Light Assembly LH
- W 2 Sliding Roof Control ECU
- W 3 Vanity Light Assembly RH
- W 4 Inner Rear View Mirror Assembly
- W 5 No. 2 Room Light Assembly
- W 6 Rain Sensor
- W 7 Map Light Assembly
- W 8 Visor Assembly LH
- W 9 Visor Assembly RH
- W 10 No. 1 Room Light Assembly LH
- W 11 No. 1 Room Light Assembly RH
- W 12 No. 2 Room Light Assembly LH
- W 13 No. 2 Room Light Assembly RH
- W 14 Television Display Assembly
- W 15 No. 1 Room Light Assembly
- W 16 No. 2 Room Light Assembly

- X 1 Rear Television Camera Assembly
- X 2 Back Door Lock Assembly
- X 3 Glass Hatch Opener Switch Assembly
- X 4 Back Window Lock Assembly
- X 6 Luggage Electrical Key Switch
- X 7 Rear Window Defogger (Back Door Glass)
- X 8 Rear Window Defogger (Back Door Glass)

Position of Parts in Body <LHD 5-Door>



Position of Parts in Body <LHD 5-Door>

