


■ DAYTIME RUNNING LIGHT SYSTEM

- This system is optional equipment on some LHD models for Europe.
- This system is designed to automatically activate the headlights (LO beam) and taillights during the daytime to keep the car highly visible to other vehicles.
This system is controlled by the body ECU.
- This system is enabled when the conditions given below are met.
 - Ignition switch ON condition
 - Light control switch OFF condition
 - Alternator L terminal signal input (Engine Running Condition)

► System Diagram ◀



233BE05